


驱动器安装尺寸

DRIVER MOUNTING DIMENSIONS

E安装尺寸图 (单位:mm)

E INSTALLATION DIMENSION DIAGRAM




E1适配电流 (A) 3-6

E2适配电流 (A) 7-12

E3适配电流 (A) 16-32

38A以上安装尺寸图 (单位:mm)

ABOVE 38A INSTALLATION DIMENSION DIAGRAM



38A安装尺寸图对照表

电流 (A)	38-45	60	75-90	110-170
A	220	226	262	305
B	149	150	160	160
C	363	439	499	605
D	349	428	488	594
E	200	250	251	236
F	5.5	6.5	6.5	6.5